



Custom Office Beverage  
Service Since 1974

## ***Bloomfield Silex Brewers Maintenance Procedures***

[www.coffee-mill.com](http://www.coffee-mill.com)

### ***CAUTION – HOT SURFACES AND HOT WATER***

**If your brewer is running slowly, please try the following steps:**

1. To get water flow back to normal, unplug the brewer and remove the top of the brewer by removing the two screws (located near the back of the brewer).
2. Remove two hoses from the top of the holding tank: the inlet and outlet.
3. Once the hoses have been removed, use a small screwdriver and push any debris out of the opening in the tank to remove any lime build up.
4. Reattach the hoses, making certain that they are fully inserted into the opening.
5. With the top of the brewer still off, plug the brewer into the power outlet and run a pot of water through the brewer to finish cleaning out the water line, and to also check for leaks.
6. When you are satisfied that the hoses are properly connected, replace the top of the brewer.
7. You are now ready to resume brewing coffee.

**For questions or service, please contact us anytime!**

**Phone: 763-391-7997**

**Email: [info@coffee-mill.com](mailto:info@coffee-mill.com)**

Revised 09/08